Parapet Rake Trim
[FL-1060]

Fastener #9
10 x 1$\frac{1}{2}$" LL Wood Fastener
W/Washer At 1'-0" O.C.

5V Crimp Roof Panel

Field Cut Panel As
Required And Bend
Up $\frac{1}{2}$" Leg

Tri-Bead Sealant $\frac{3}{16}$" x $\frac{7}{8}$"
[HW-504]

Finishing Off Module

Masonry Wall (Not By MBCI)

Field Saw Cut

Urethane Sealant [HW-540] Cont.

Tri-Bead Sealant $\frac{3}{16}$" x $\frac{7}{8}$"
[HW-504]

Fastener #209
14-10 x 2" Deck Screw
At 2'-0" O.C. (Pre-Drill)

Counterflash [FL-341]

Parapet Rake Trim [FL-1060]

Fastener #9
10 x 1$\frac{1}{2}$" LL Wood Fastener
W/Washer At 1'-0" O.C.

Tri-Bead Sealant $\frac{3}{16}$" x $\frac{7}{8}$"
[HW-504]

5V Crimp Roof Panel

Waterproof Membrane
(Not By MBCI)

5/8" Plywood Min.
(Not By MBCI)

Fastener #9
10 x 1$\frac{1}{2}$" LL Wood
Fastener W/Washer
(See Fastener
Spacing Detail)