Support Zee [T-6309]

Spacer Zee [T-6246]

Fastener #14
$\frac{1}{8}$"$\emptyset$ x $\frac{3}{16}$" Pop Rivet SS
At 1'-0" O.C.

Horizontal Designer Series
Wall Panel (Field Cut As
Required)

End In Panel Low

Window Or Wall Louver

Fastener #13A
12 x 1" Pancake Hd
Type A W/O Washer
At 2'-0" O.C.

Perimeter Sealant
(Not By MBCI)

Special Sill Trim

Fastener #14A
$\frac{1}{8}$"$\emptyset$ x $\frac{3}{8}$" Pop Rivet SS
At 1'-0" O.C.

Spacer Zee [T-5014]

Fastener #18
14 x 1" Type A W/Washer
At 1'-0" O.C.

Horizontal Designer Series
Wall Panel (Field Cut As
Required)

Fastener #4A
1/4-14 x $\frac{7}{8}$" SD W/ Washer
At Each Connection

Fastener #18
14 x 1" Type A W/Washer
(1) Per Connection

Moisture Barrier
(Not By MBCI)

$\frac{5}{8}$" Plywood Min.
(Not By MBCI)

Installation